

## IR CONTROLLER USER MANUAL



IR Controller

### Introduction

IR Controller is a Z-Wave/IR Repeater to control all IR based Devices, It can operate on two AA Batteries or 5V DC. Since this product is based on Z-Wave Technology it can also be operated remotely within the home or from outside. IR Repeater can be used out of the box and needs no configuration. However, it supports different configuration parameters that extend its functionality.

### Technical Specification

Power Input	5V-1A Max.(DC Adapter) or 2 x AA Batteries
Maximum Load per Channel @240VAC	NA
Cumulative Load - 4 Channels Muxed @240VAC	NA
Operating Temperature	-10° to +55°C
Temperature Sensing	5° to +40°C (+/-2°)

Relative Humidity	8% - 80%RH
Dimensions	71mm x 71mm x 27mm
Radio Frequency	865.2MHz (IN)
Surge Protection	NA
Typical Line of Sight Range	10~15m Indoor /30m Outdoor
Plastic Housing	Cover - PC, Case ABS
Supported Load Type	IR Based devices like AC, AV, Setup Box, Projectors & Fan

### Installation Steps

#### Inclusion from the Network :

The term "INCLUSION", "ADDING", "PAIRING" implies the same meaning. Inclusion is a process by which a new Device (or a Device which previously got out of Z-Wave Network by force reset or Exclusion process) can join a new or existing Z-Wave Network. Basically, two steps are involved in Inclusion process:

1. Set Gateway/Controller into the inclusion mode (See Gateway User Manual).
2. Set Device into the Learn Mode.

- Learn mode can be invoked by one-time short press of Prog Node\_Info Key (black colour button behind the Device).
- User Indication: Blinking of green LED shows successful Inclusion.

#### Exclusion from the Network :

The term "EXCLUSION", "REMOVING", "UNPAIRING" implies the same meaning. Exclusion is a process by which an already included Device can be made to leave its existing Z-Wave Network. Upon Exclusion all user configuration parameters are set to their default values. Exclusion of Device can be done in two steps:

1. Set Gateway/Controller into the Exclusion Mode (See Gateway User Manual).
2. Set Device into the Learn Mode.

- **User indication:** Blinking of red LED shows successful Exclusion.
- **Learn Mode** can be invoked by one-time press of NODE\_INFO key.

### LED Indications

#### The Device with the help of on-board LEDs reflects the following states:

RED LED blinking (1 s approx.): Device is not a part of any Network, started Learning Mode and ready to be included into any Z-Wave Network.

GREEN LED blinking (1 s approx.): Device is already a part of Z-Wave Network, started Learning Mode and ready to be excluded from Z-Wave Network.

GREEN LED Flash one time (1s approx.): Device is currently communication with Gateway/Controller.

RED LED glow continuously: Device is in IR code Learning Mode.

RED & GREEN LED fast blinking: Firmware upgrade via OTA is in progress.

### Force Resetting the Device

Device reset can be invoked by press and hold NODE\_INFO/Pairing Button for more than 10 seconds. User indication: Flashing of RED and GREEN LED shows a successful reset. Once the Device resets, it will no longer be a part of the Z-Wave Network and all the user configuration parameters are set to their default values.

**Note: Please use this procedure only when the Network Primary Controller is missing or otherwise inoperable.**

## Product Configuration Settings

### Configuration Parameters

The product is factory set to default values so that it can operate normally without the need for any additional parameter setting. Below is the description of parameters supported by this product to further enhance its functionality.

- **Parameter 01:** Temperature sensor polling time.
- **Size:** 1 Byte
- **Range:** 1 to 60 (in minutes)
- **Default:** 1 (in minutes)
- **Description:** This parameter decides the polling time of temperature sensor value.
- **Parameter 02:** Power Mode.
- **Size:** 1 Byte
- **Range:** 0 - 1(0 - Battery, 1 - Adapter)
- **Default:** 0 (Battery)
- **Description:** This parameter decides the power supply for the Device.
- **Parameter 03:** AC & AV Key Learning
- **Size:** 1 Byte
- **Range:** 0-1(0 - AV, 1 - AC).
- **Default:** 0 (AV)
- **Description:** This parameter decides which remotes is being learnt : 0 for AV and 1 for AC.

## Adding Remotes

After the inclusion of the device to add the remotes for controlling follow the below steps :

1. Go to Devices.
2. Click on the Edit Button for the IR Controller.
3. Click on the Add Button.
4. Select the remote.
5. Click Add.
6. Remote gets added to the App.

### Note:

1. Maximum limit for the remotes is 4 that is you can control 4 remotes using one IR Controller.
2. Voice enabled Bluetooth and RF remotes cannot be controlled through IR Controller.

## Key Synchronization (Learning)

After adding the remote for key synchronization follow the below steps:  
Need to Configure the Parameter before doing the Key Synchronization, Input Parameter number 3 and give value 1 for AC Remote Learning and parameter number 3 and value 0 for AV Key Learning.

- Click on Key Synchronization



Name **IR**

Force to remove or replace

Key learning


Name the channel

Configuration

Signal strength **Bad**

Assigned to room **Unassigned**

- Click on the button for which Key Synchronization needs to be done.







- Now press the same button from the Actual Physical Remote



Repeat the same process for all the buttons.


## Installation Details




## Installation

### A. Battery installation


1. Remove the top cover by sliding



2. Place the battery to the battery compartment




3. Close the top cover by sliding .




#### B. Adapter installation


##### 1. Remove the top cover by sliding



##### 2. Connect the adapter to the module



##### 3. Close the top cover by sliding .



 Dispose of the Device separately from household waste at an official collection point. Professional recycling protects people and the environment against potential negative effects.

#### Recommendations

- Inclusion has to be done within 3 meters.
- If there are signs of water seeping into the electrical box, turn off the MCB and disconnect the power supply to avoid short circuits.

#### Common Issues

**Pairing not working:** Confirm that the Gateway and the IR Module are within 3 meters from each other while adding to the Gateway.

#### Warranty

Standard warranty of 24 months from the date of supply is applicable for all products.

##### The warranty shall not cover:

- Mechanical damages caused by impact, falling or dropping the device or their object, unauthorized use or not observing the Operation Manual.
- Damages resulting from external causes, for example: flood, storm, fire, lightning, natural disasters.
- Damages resulting from surges in the power and/or Telecommunication Network, improper connection to the grid in a manner inconsistent with the operating manual, or from connecting other devices not recommended by the Manufacturer.
- Damages resulting from the use of spurious spare parts or accessories improper for given model, repairing and introducing alterations by unauthorized Technicians.
- Defects caused by operating inoperable Devices or accessories.

**MEDHA**  
*By Confio*

For any technical and support queries,  
please contact the Manufacturer

CONFIO TECHNOLOGIES PRIVATE LIMITED  
#3500/A, 80 Feet Road,  
Raghuvanahalli, Bangalore - 560062  
Karnataka, India

Email: [support@confiolabs.com](mailto:support@confiolabs.com)  
[www.confiolabs.com](http://www.confiolabs.com)